





### BATTERIES - ELEMÉK

- EN** • Use new batteries to obtain best performance.  
• Alkaline batteries recommended.  
• Rechargeable batteries are to be removed from the toy before being charged.  
• Rechargeable batteries are only to be charged under adult supervision.  
• Non-rechargeable batteries are not to be recharged.  
• Different types of batteries or new and used batteries are not to be mixed.  
• Only batteries of the same or equivalent type as recommended are to be used.  
• Batteries should be replaced by an adult.  
• Cells should be replaced in the correct polarity.  
• Exhausted batteries are to be removed from product.  
• The supply terminals are not to be short-circuited.  
• Batteries are to be removed from product before long term storage.  
• Do not dispose of batteries in fire.  
• Batteries should be recycled or disposed of as per state and local guidelines.



## LET'S TALK! BESZÉLGESSÜNK!

**EN** Wraptiles may not have the best manners but we like to chat... Talk to me or place me next to other Wraptiles and we'll chat, argue and laugh! The more we talk the more our mood improves.

**HU** A Wraptile nem a legjobb beszélgető partner, de imád kommunikálni... Beszélj hozzá és visszaérök, vagy tegyél egy másik hüllő mellé és beszélgetünk, morgunk vagy nevünk. Minél többet beszélgetünk, annál jobb lesz a kedünk.




## SHAKIN' IT UP! RÁZZ FEL!

**EN** Take me for a ride, bust a move or just get active with me.

- Shake me and I'll get dizzy!
- Do it sparingly though – too much shaking could make me angry!

**HU** Rázz fel! Vigyél magaddal, mozgass vagy csak interaktív lelem.

- Ha megrázol szérdűlni fogok.
- Azt azért vésd az eszedbe, a től sok rázásról duhós leszek."



## SLEEPING ALVÁS

**EN** All this activity can tire me out!

I go to sleep in two ways.

**1. Hold me upside-down.**

You'll hear me yawn and I'll begin to snore. This is the quickest way to send me to sleep.

**2. Leave me alone.**

For a while, I'll call out for attention. I might even repeat your recorded phrase! In a matter of minutes, I'll start yawning and go to sleep.

In either case, eventually my eyes will fade – this means I'm asleep.

You can wake me up at any time by doing any of the following:

- Pressing the Record Button
- Tilt head to Playback/Attack
- Switching me Off then back ON

**HU** Az aktivitás kimeríti a hüllőt!

Két módon merül öléomba.

**1. Forgasd fejét lefelé,** általam fog majd horkolni kezd.

**2. Hagyd békán.** Egy kis idő múlva jelzi, hogy figyelemre von szüksége, ha ezt nem kapja meg visszaítja a hangszünetedet is. Pár perc elteltével ásítózní kezd és mély öléomba merül.

Mindkét esetben kialszik a szeme.

Ha fel szeretnék ébreszteni:

- Nyomd meg a Record gombot
- Hajtsd hátra a fejét
- Kapcsold ki, majd vissza"

## TROUBLESHOOTING PROBLÉMAELHÁRÍTÁS

### Wraptile function does not match instructions

- Always ensure switch is in ON position, not OFF or TRY ME.

### To erase a previously recorded message

- To erase a previously recorded message, do one of the following:
  - Press the Record Button.
  - Move switch to TRY ME, then back to ON.

### Wraptile does not repeat my entire recorded message

- When ON, Wraptiles will record up to 10 seconds of sound.
- Ensure there are no significant pauses when saying your message – your Wraptile will think you've stopped talking and begin playback.
- Try speaking closer to the microphone by facing the front of your Wraptile.
- Make sure you're in a quiet area with no background noise and you're holding your Wraptile close to your mouth.

### My Wraptile keeps talking

- Your Wraptile will keep talking if:
  - It's near other Wraptiles.
  - There's excessive noise in the play environment.
- If you want your Wraptile to stop chatting, place it in a quiet area, or send it to sleep by holding it upside-down.

### Wraptile falls off my arm

- To ensure your Wraptile remains attached to your arm (or wherever you've wrapped it), push both sides of Support Strip together.

- HU**
- Ha a hüllő nem működik megfelelően, minden győződj meg róla, hogy be van kapcsolva. Ahhoz, hogy forról a hangszünetet: nyomd meg a Record gombot, vagy mozgasd a kapcsolót a TRY ME-re, majd ON-re. • Ha nem a teljes üzenetet isméri meg, akkor vedd igényelme, hogy 10 másodpercre képes csak szünetekkel hogysz, akkor azt hiheti befejezetlen a mondanivalódat.
  - Fontos, hogy a hőter ne legyen zajos és a mikrofonra beszél.
  - Ha a hüllő még mindig beszél amikor már nem szeretné, akkor távolítsd el a többi hüllő könyvezetből, vagy a zajos.
  - Hogy ne essen le a kezdről, alaposan rögzítsd a biztonsági tépőzárak segítségével.

## TROUBLESHOOTING PROBLÉMAELHÁRÍTÁS

### Shaking isn't working

- Moving your Wraptile gently may not result in a response.
- Either invert (turn your Wraptile upside-down) rapidly multiple times, or shake them quickly.

### Can't change Wraptile's mood

- Certain interactions move your Wraptile towards being happy, while others will move it angry:
  - Happy Talking, Recording and Playback/Attack
  - Angry Shaking, no interaction
- You can always reset the mood of your Wraptile by switching it OFF, then back ON.

### Wraptile's eyes aren't lighting up

- During some stages of sleeping, your Wraptile's eyes will not light up.
- Low or depleted batteries may also cause this result; replace both batteries with fresh ones as described in this manual.

### Wraptile won't sleep

- If there's excessive noise in the play environment, your Wraptile will not sleep.
- If you want your Wraptile to sleep, stop interacting with it and place it in a quiet area.
- If you're attempting to put your Wraptile to sleep by holding it upside-down, ensure you're not shaking it.

### Wraptile falls off your arm

- Ha a hüllő nem reagál a rövarszerre, lehet hogy túl finoman csinálod. Forrasd fel le gyorsan, vagy rázz kissé erősebben.
- Ha nem változik a kedve, bizonyra azért lehet, mert egyszerre dühített és boldogított. (Boldog: beszélgetésből, hangoztatásból, visszajátszásból, támadaiból/Dúhás: rázásból, elhangosításból.)
- A hüllő kedve minden lenullázódik, ha ki-be kapcsolód.
- Ha nem világít a szeme, akkor őszik, vagy merülnek az elemek, cseréld ki őket.
- Ha a hüllő nem akar elaludni, győződj meg róla hogy csendes helyen van, nem rázod és nem interakcsisz velé.

## FCC STATEMENT FCC NYILATKOZAT

**EN** This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

**HU** A készüléket tesztelük, és az FCC-szabványat 15. részének megfelelően „B” osztályú digitális eszköz előírásainak felel meg. A korlátozásoknak megfelelő védelmét nyújtanak a körös interferenciával szemben. A készülék rádiófrekvenciás energiát hoz létre, használ és sugárít.

**FIGYELEM:** Azok a módosítások vagy átalakítások, amelyeket a megfelelőtől teljesen különállóan kiválasztva végezheted, nem garantálható a berendezés üzemeltetésére.

**JEGYZET:** Ha a készülékel nem a gyártó általánosan elérhető garancia, vagy egy olyan telefonszolgáltató hálózatban van, amelynek támogatására a készülék körös interakcióval okozta rádiónagyon megjavasoljuk, hogy az interakció megszüntetése érdekében. A készüléket a következő lépésekkel javítsa vissza:
 

- Forrassa el vagy hagyja át a vevőantennát. Növelte a fávalsgot a készülék és a vevő között.
- Csatlakoztassa a készüléket a vevőegységtől különboző hálózati aljzathoz. Kérje a kereskedőt vagy szakképzett szerviz segítségét.